



① PREPARE ② TREAT ③ MAINTAIN

EXTERIOR WOOD CLEANER



surface

Effective cleaning

Effective, yet mild cleaning product. Removes heavy build-up of dirt and grime. Extends the lifetime of the wood.



eco

Environmentally friendly

Does not harm plants, flowers or grass. Water-based. VOC-free.



cleaning

Easy to use

Ideal for manual cleaning on smaller surfaces and mechanical cleaning on deckings.



treatment

For pre-treatment

Prepares the surface for subsequent treatment. Opens the grain of the wood, allowing the following product to soak into the wood more easily.



PRODUCT DESCRIPTION

Exterior Wood Cleaner was developed for the thorough cleaning of all types of wood surfaces, such as terraces, garden furniture, fences, canopies, doors and windows. The product quickly and efficiently dissolves dirt, thereby assuring an optimal surface for subsequent treatment.

APPLICATION AREA

For new and old wood. Ideal for surfaces such as garden furniture, terraces, fences, canopies, window frames, doors and carports. Can also be used on masonry and concrete.

Product information

Coverage: 100 m²/L

Packaging: 1L - 2.5L



WORK DESCRIPTION

Preparation

Treatment should only be performed in dry weather conditions. Avoid direct sunlight and excessive heat. Remove all loose foliage, branches, etc. and then soak the wood with water. Use a garden hose if possible.

Note

Exterior Wood Cleaner can also be used on masonry and concrete.



TREATMENT

- 1 Mix Exterior Wood Cleaner with water in a ratio of 1:2 - 1:10, depending on how dirty the wood is.
- 2 Apply the cleaner in an even coat, using a brush or spray nozzle. Leave the cleaner to work for five minutes.
- 3 Scrub in the longitudinal direction of the wood grain using a stiff-bristled brush, until the surface is clean. We recommend WOCA's silicon brush or terrace brush for the best results.
- 4 Rinse the surface with plenty of water and leave the wood to dry for 24-48 hours. The wood must be completely dry before after treatment with oil, paint or impregnation. If a completely smooth surface is desired, any uneven wood fibres can be removed with sandpaper grit 180-240 before oiling.