



1 PREPARE 2 TREAT 3 MAINTAIN

MASTER BASE PRIMER, EXTRA WHITE

PRODUCT DESCRIPTION

Master Base Primer, Extra White is a thick, water-based wood primer that is ideal for areas where an intensive light look is required. The primer seals the wood and minimises the tannic acid penetration and side-bonding. It is only suitable for untreated or sanded surfaces of light woods and works as a powerful basic lacquer

before treatment with other water-based WOCA floor lacquers.

APPLICATION AREA

Lacquering new, untreated and sanded fir, oak, ash and beech.



120 min

Quick-drying

Sandable after approx. 120 min. at 20°C and 30-60% RH.



application

Economical in use

Very quick, easy and economical to use. Reduced overlapping. Water-based.



side-bondings

Reduces side-bondings

Reduces the risk of side-bondings due to a high flexibility. Minimizes penetration of tannic acid.



Product information

Coverage: 8-12 m²/L

Packaging: 5 L



WORK DESCRIPTION

Preparation

It is important that both wood and product have a temperature of min. 15°C (preferably around 20°C) and air humidity of approximately 40-60 %. Make sure that the room is well-ventilated for optimal evaporation and drying time. Untreated floors must be free of dirt, grease, wax and dust.

Final sanding must be done with fine sandpaper (grit 120). Vacuum carefully afterwards. The surface must be free of dirt, grease, wax and dust. The primer must be room temperature before use. Shake the Master Base Primer thoroughly before use.

Note

It is extremely difficult to apply Master Base Primer, Extra White to diagonally-aligned wood (herringbone parquet etc.) without visible overlap, so we advise extra caution.

If drying times are not followed, this can result in poor adhesion and reduced resistance. For each layer of Master Base Primer, drying times will be increased. High temperature and low air humidity will reduce drying times. Low temperature and high air humidity will extend drying times. Absorption of tannic acid is not considered as a valid cause for complaint.



APPLICATION

TREATMENT

- 1 Apply the primer undiluted with brush or roller, following the wood along its length, and allow the surface to dry. Please note: For a more intensive light appearance, apply another coat of primer. Sanding must be done after the first coat with 180-220 grit sandpaper (a treatment with a white-pigmented material generally requires more even sanding to prevent the pigments from sticking in the sanding grooves).
- 2 When the wanted appearance has been achieved, apply 1-2 top-coats with one of the WOCA floor lacquers. Always apply a minimum of three coats (primer and lacquer) for ideal protection.

It is not recommended to apply more than two coats of primer/lacquer per day due to risk of excessive wood swelling.