



1 PREPARE 2 TREAT 3 MAINTAIN

MASTER QP LACQUER



resistance

One day job

Dries fast without the use of hardener. It has a high resistance to water and chemicals.



5 hours

Drying time

Between coats: 2-3 hours at 20°C.
Light use: 5 hours.
Fully hard: 5-7 days



maintenance

Easy to maintain

Can be cleaned and maintained with WOCA Master Cleaner and WOCA Master Care for lacquered surfaces.

PRODUCT DESCRIPTION

Master QP Lacquer is a single-component, water-based lacquer designed for offices and other commercial areas with medium traffic. Using this lacquer simplifies and speeds up the application process, as it dries fast and is easy to use. It has a high resistance to water and chemicals, and preserves the light Nordic look, as very little colour is added to the

wood. This indoor climate labelled lacquer is applied in a convenient and safe way, and ensures a comfortable indoor climate afterwards.

APPLICATION AREA

For lacquering new, untreated and newly-sanded wood floors in commercial areas. Ideal for all types of wood.

Product information

Coverage: 8-10 m²/L

Packaging: 5 L

Gloss: Matt/gloss approx. 10 and silk-matt/gloss approx. 20.





WORK DESCRIPTION

Preparation

It is important that both wood and lacquer have a temperature of min. 15°C (preferably around 20°C) and air humidity of approx. 50%. Make sure that the room is well-ventilated for optimal evaporation and drying time.

For the final sanding to bare wood, use grit 100-120 sandpaper or sanding pad. Vacuum thoroughly and wipe the floor down afterwards, using a tightly-wrung water-soaked mop/cloth. Please note: WOCA Intensive Wood Cleaner can help to remove contaminants from fully sanded wooden floors before priming or lacquering. Please allow floor to fully dry overnight. The floor must be completely dry before priming or lacquering. When priming, use WOCA Master Base Primer for newly sanded wood to reduce side bonding. Alternatively, try WOCA Master Multi Primer for exotic wood species or old wood previously treated with oil or wax.

Note

If drying times are not followed, this can result in poor adhesion and reduced resistance. For each coat of lacquer, drying times will be increased. High temperature and low air humidity will reduce drying times. Low temperature and high air humidity will extend drying times. When applying three coats of lacquer in one day, be careful about old floors and engineered parquet.


Maintenance and cleaning

Weekly cleaning: Master Cleaner, #684525

Half-yearly care: Master Care, #684125



APPLICATION X 2



SANDING



APPLICATION

TREATMENT

- 1 Primer and a coat of Master QP Lacquer should be applied undiluted, using a brush or roller. Alternatively, two coats of lacquer can be applied. Leave the surface to dry until next day. Please note: Under ideal conditions (20-25°C and 40-60% RH), a third coat can be applied the same day. Follow the instructions below.
- 2 Sand the surface with grit 120-200 and vacuum clean the surface thoroughly.
- 3 Apply the final coat of undiluted Master QP Lacquer.

The freshly-lacquered floor is suitable for cautious use after approx. 5 hours. Do not place furniture etc. on the floor until at least 24 hours after the final coat of lacquer. The floor will be ready for normal use after approx. 5-7 days, after which rugs etc. can be placed on the floor.

Water and coloured fluids, such as red wine and coffee, must be wiped off immediately to prevent staining.